

# BOOST LOP – Train 2

## Column Flushing MAM-102 FWKO ILIC-102

---

**PURPOSE:** Level Switch Test

**OBJECTIVE:** Safely Shutdown Process Testing

**SCOPE:** Safely flush level column for ILIC 102

### 1 CLASSIFICATION DATA:

**Approved:** *August 1, 2017*

**Review Cycle:** [2] year

**Reviewers: Local SMEs**

**Approver: Operations Supervision**

Curt Bourgeois

Carmen Berry

**Craft:**  
Process Engineer

**Man-hours:**  
20 min

### SAFETY, ENVIRONMENTAL, AND ASSET CONSEQUENCES

| <u>RAM Rating</u>                | <u>Severity &amp; Likelihood</u>                             | <u>Rating</u> |
|----------------------------------|--------------------------------------------------------------|---------------|
| <b>Safety Consequence</b>        | Slight Injury,<br>Heard of in industry                       | P1B           |
| <b>Environmental Consequence</b> | No Impact,<br>Never heard of in industry                     | E0A           |
| <b>Asset Consequence</b>         | Slight damage less than<br>\$10,000,<br>Heard of in industry | A1B           |

| <b>Permits and plans (those checked are required)</b>    |                                      |   |                                         |
|----------------------------------------------------------|--------------------------------------|---|-----------------------------------------|
| X                                                        | JSA                                  |   | Hot Work Permit                         |
|                                                          | Safe Work Permit                     |   | Fall Rescue Plan                        |
|                                                          | Safe Work Plan                       |   | Confined Space Entry                    |
|                                                          | Lock Out/Tag Out                     |   | Leadership Walkthrough                  |
|                                                          | Isolated work is allowed             | X | Trip Tricky Tasks                       |
|                                                          | Step Sign off Required (High Rating) | X | Statement of Fitness (may be required)  |
| <b>Special PPE Required (those checked are required)</b> |                                      |   |                                         |
|                                                          | Chemical Resistant Gloves            |   | Additional Hearing Protection-Ear Muffs |
|                                                          | Face Shield                          |   | Respirator                              |
|                                                          | Chemical Resistant Goggles           |   | Fresh Air Pack                          |
|                                                          | Chemical Resistant Apron             |   |                                         |

### **TOOLS/EQUIPMENT REQUIRED**

- Radios
- Hand tools
- Proper PPE

### **2 CONSUMABLES (MMR IF APPLICABLE)**

| MMR # | Consumables Description | Qty |
|-------|-------------------------|-----|
|       | N/A                     |     |

### **3 PARTS (MMR IF APPLICABLE)**

| MMR # | Parts Description | Qty |
|-------|-------------------|-----|
|       | N/A               |     |

### **SPECIAL EXECUTION CONSIDERATION**

1. All procedures require sign off upon completion each step.

## WORK INSTRUCTION

| Signoff   | Operation Step                                                                                                                                                                                                                  |
|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. _____  | Have CRO place ILIC - 102 in Manual Control.                                                                                                                                                                                    |
| 2. _____  | Have CRO communicate when controller is in Manual.                                                                                                                                                                              |
| 3. _____  | Close manual column valve M102 - 9. Lower isolation valve on level column.                                                                                                                                                      |
| 4. _____  | Close manual column valve M102 - 11. Upper isolation valve on level column.                                                                                                                                                     |
| 5. _____  | Remove plug.                                                                                                                                                                                                                    |
| 6. _____  | Open drain valve on bottom of float cage.                                                                                                                                                                                       |
| 7. _____  | Drain fluids into a bucket with secondary containment.<br><br>Trapped pressure may be present.<br>Uncontrolled pressure release could result in bodily injury or death.<br>Wear gloves and safety glasses.                      |
| 8. _____  | Remove plug and open vent on top of float cage and vent to a location away from any personnel. Slowly open vent--releasing pressure a little at a time.<br><br><i>Note: This will verify that all fluids have been drained.</i> |
| 9. _____  | Close the vent valve and re-install plug.                                                                                                                                                                                       |
| 10. _____ | Close the drain valve and re-install plug.                                                                                                                                                                                      |
| 11. _____ | Open manual column valves M102 - 11. Upper isolation valve on level column                                                                                                                                                      |
| 12. _____ | Open manual column valves M102 - 9. Lower isolation valve on level column                                                                                                                                                       |

13.        \_\_\_\_\_      Observe that the fluid rise and that the ILIC returns to a normal operating condition.

---

14.        \_\_\_\_\_      Dispose of fluids collected from performing the task by dumping in Wet Oil Tank.

---